

DIGITAL

RICE COOKER



REISHUNGER



	Rice	Water	Mode	Cooking time*
 BASMATI RICE	1	: 1.25	White	40 min
 WHOLEGRAIN BASMATI RICE	1	: 2	Brown	62 min
 SUSHI RICE	1	: 1.25	Sushi	40 min
 SADRI RICE	1	: 1.25	White	40 min
 SADRI DUDI RICE	1	: 1.25	White	40 min
 JASMINE RICE	1	: 1.25	White	40 min
 WHOLEGRAIN JASMINE RICE	1	: 2	Brown	62 min
 RED JASMINE RICE	1	: 2	Brown	62 min
 BROWN RICE	1	: 2	Brown	62 min
 RED RICE	1	: 2	Brown	62 min
 STICKY RICE	1	: 1.25	Sushi	40 min
 MOCHI RICE	1	: 2	Brown	62 min
 PURPLE RICE	1	: 2	Brown	62 min
 BLACK RICE	1	: 2	Brown	62 min
 WILD RICE	1	: 2	Brown	62 min
 QUINOA	1	: 2	Quinoa	30-35 min
 RED QUINOA	1	: 2	Quinoa	30-35 min
 BLACK QUINOA	1	: 2	Quinoa	30-35 min
 WILD RICE BASMATI MIX	1	: 1.25	Rice	40 min
 BASMATI LENTIL QUINOA MIX	1	: 1.25	Rice	40 min

We do not recommend preparing the following types of rice in our rice cooker:
RISOTTO RICE, PUDDING RICE and PAELLA RICE.

*The cooking time refers to 2 servings. All times are guidelines.

