

MINI DIGITAL

RICE COOKER



REISHUNGER



| | Rice | Water | Mode | Cooking time* |
|---|------|--------|----------|---------------|
|  BASMATI RICE | 1 | : 1.25 | White | 26 min |
|  WHOLEGRAIN BASMATI RICE | 1 | : 1.75 | Brown | 62 min |
|  SUSHI RICE | 1 | : 1.25 | Sushi | 30 min |
|  SADRI RICE | 1 | : 1.25 | White | 26 min |
|  SADRI DUDI RICE | 1 | : 1.25 | White | 26 min |
|  JASMINE RICE | 1 | : 1.25 | White | 26 min |
|  WHOLEGRAIN JASMINE RICE | 1 | : 1.75 | Brown | 62 min |
|  RED JASMINE RICE | 1 | : 1.75 | Brown | 62 min |
|  BROWN RICE | 1 | : 1.75 | Brown | 62 min |
|  RED RICE | 1 | : 1.75 | Brown | 62 min |
|  STICKY RICE | 1 | : 1.25 | Sushi | 35 min |
|  MOCHI RICE | 1 | : 1.75 | Brown | 62 min |
|  PURPLE RICE | 1 | : 1.75 | Brown | 62 min |
|  BLACK RICE | 1 | : 1.75 | Brown | 62 min |
|  WILD RICE | 1 | : 1.75 | Brown | 62 min |
|  WILD RICE BASMATI MIX | 1 | : 1.25 | Standard | 26 min |
|  BASMATI LENTIL QUINOA MIX | 1 | : 1.25 | Standard | 26 min |

We do not recommend preparing the following types of rice in our rice cooker:

RISOTTO RICE, PUDDING RICE and PAELLA RICE.

*The cooking time refers to 2 servings. All times are guidelines.

